

Model No.	Ref. No.	Parts No.	UPDATE NO	Chinese Description	Description of Goods	Quantity (SET)
1100E	E01	2 12251-SEC0-0000		气缸垫总成	Gasket Assy., Cylinder	1
1100E	E01	2 12251-SEC0-0000		气缸垫总成	Gasket Assy., Cylinder	1
1100D	E01	11 17620-SEC0-0000		加油口盖	Cap, Oil-filling Port	1
1100D	E01	13 12630-SEC0-0000		气缸盖罩密封垫	Seal, Cylinder Cover Shroud	1
1100D	E02	4 15410-SEC0-0000		机油滤清器总成	Filter Assy., Engine Oil	2
1100D	E04	4 15410-SEC0-0000		机油滤清器总成	Filter Assy., Engine Oil	3
1100E	E07	19 31341-SEC0-0000		节气门体密封垫	Seal, Throttle	1
1100E	E07	24 17119-SEC0-0000		进气歧管密封垫	Seal, Air-intake Manifold	2
1100E	E09	3 18361-SEC0-0000		排气歧管隔热垫总成	Heat-insulating Washer, Air-exhaust Manifold	0
1100E	E09	3 18361-SEC0-0000		排气歧管隔热垫总成	Heat-insulating Washer, Air-exhaust Manifold	1
1100D	E14	2 20102-SEC0-0001		右支架软垫总成	Cushion, Right Suspension Assy.	1
1100D	E14	9 20104-SEC0-0001		后悬挂软垫总成	Cushion, Rear Suspension Assy.	1
1100D	E14	11 20106-SEC0-0001		左悬挂架软垫总成	Cushion, Left Suspension Assy.	1
1100D	E19	19 24552-SEC0-0000		五档同步器齿环	Ring, 5th Gear Synchronizer	0
1100D	E19	20 24558-SEC0-0000		五档同步器齿环弹簧	Spring, 5th Gear Synchronizer ring	0
1100D	E19	22 24557-SEC0-0000		五档同步器弹簧	Spring, 5th Gear Synchronizer	0
1100D	E19	23 24555-SEC0-0000		五档同步器滑块	Slider, 5th Gear Synchronizer	0
1100D	E19	24 24553-SEC0-0000		五档同步器齿毂	Hub, 5th Gear Synchronizer	0
1100D	E19	25 24554-SEC0-0000		五档同步器齿套	Collar, 5th Gear Synchronizer	0
1100D	E20	3 24216-SEC0-0000		五档换挡拨叉	Gearshift Fork, 5th Gear	0
1100E	E21	38 24739-SEC0-0000		换位拨块	Block, Gearshift	0
1100D	F01	11 50197-BDB0-0000		挡泥板	Mudguard	8
1100D	F01	14 50250-BEB0-0000		左前挡泥板支架	Mudguard Bracket, Left Front	0
1100D	F01	18 50270-BEB0-0000		左后挡泥板支架	Mudguard Bracket, Left Rear	0
1100D	F01	20 82101-BEB0-0000	82101-BEB0-0000-B6	后货架	Carrier Assy., Rear	1
1100D	F01	28 85010-BEB0-0001		侧后薄板	Lamella Thin plate Rear	1
1100D	F01	36 64313-BEB0-0000		地板塑料扣钉	Floor plastic button	30
1100D	F01	37 50240-BEB0-0000		右前挡泥板支架	Mudguard Bracket, Right Front	0
1100D	F01	38 50260-BEB0-0000		右后挡泥板支架	Mudguard Bracket, Right Rear	0
1100D	F01	20-2 82200-BEB0-0000-B6		后尾翼	Guard, Rear	0
1100D	F02	6 17910-BEB0-0000		油门线	Cable, Throttle	1
1100D	F02	51.2 45250-BEB0-0000		离合器分泵	Clutch Control Pump, Subsidiary	1
1100D	F03	5 51122-BEB0-0000		杆端球关节φ16×1.5	Ball Knuckle, Bar End φ16×1.5	16
1100D	F03	5 51123-BEB0-0000		杆端球关节φ16×1.5 (外螺纹)	Ball Knuckle, Bar End φ16×1.5	40
1100D	F03	5 51122-BEB0-0000	51123-BEB0-0000	杆端球关节φ16×1.5	Ball Knuckle, Bar End	16
1100D	F03	6 90250-16B01-0A		六角薄螺母M16×1.5	Nut, Hex M16x1.5	20
1100D	F03	9 90140-12060-2B		六角法兰面螺栓 M12×1.25×60	Bolt, Flange M12×1.25×60	30
1100D	F03	10 90210-12B01-2B		六角法兰自锁螺母M12×1.25	Lock Nut, Flange M12×1.25	30
1100D	F03	12 90292-BEB0-0000-0C		I形六角开槽螺母M16×1.5	Nut, I-slot M16×1.5	12
1100D	F03	13 94200-25400-0C		开口销2.5×40	Pin Cotter 2.5×40	20
1100D	F03	17 90294-BEB0-0000-0E		I形六角开槽螺母M20×1.5	Nut, I-slot M20×1.5	2
1100D	F03	21.2 45105-BEB0-0000		刹车蹄块	Brake Pad	4
1100D	F03	21.3 44101-BEB0-0000		制动分泵放气嘴座	Washer Valve(On Brake Cylinder assembly)	4
1100D	F03	21.4 44102-BEB0-0000		制动分泵放气嘴	Stem,Valve(On Brake Cylinder assembly)	4
1100D	F03	21.5 44103-BEB0-0000		制动分泵放气嘴帽	Cap,Valve(On Brake Cylinder assembly)	8
1100D	F03	21.6 42109-BEB0-0000		骨架油封	Oil seal	4
1100D	F03	30 44901-BEB0-0000-0D		辐板轮安装螺母	Nut, Front wheel Arm	4
1100D	F03	31 44691-BEB0-0000		轮轴盖	Cap, Front and Rear Wheel Axle	4
1100D	F03	33 51121-BEB0-0000		杆端球关节φ18×1.5 (外螺纹)	Ball Knuckle, Bar End φ18×1.5	12
1100D	F03	34 90250-18B01-0A		六角薄螺母M18×1.5	Nut, Hex M18x1.5	10
1100D	F03	36 51201-BEB0-0000		摆臂防尘盖	Dust Cover	16
1100D	F03	7-1 51151-BEB0-0011-B6		前双A上摆臂 (左)	Front Double-A Swing Arm, Upper, left	0
1100D	F03	37-1 52151-BEB0-0011-B6		前双A下摆臂 (左)	Front Double-A Swing Arm, Lower, left	0
1100D	F03	38-1 52152-BEB0-0011-B6		前双A下摆臂 (右)	Front Double-A Swing Arm, Lower, right	0
1100D	F04	7 51160-BEB0-0020		后双A上摆臂	Rear Double-A Swing Arm, Upper	2
1100D	F04	9 90140-12165-2B	90140-12165-2B-SX	六角法兰螺栓M12×1.25×165	Bolt, Flange M12×1.25×165	6
1100D	F04	10 90210-12B01-2B		六角法兰自锁螺母M12×1.25	Lock Nut, Flange M12 x 1.25	12
1100D	F04	14 90140-12120-2B		六角法兰螺栓M12×1.25×120	Bolt, Flange M12×1.25×120	1
1100D	F04	14 90140-12120-2B	90140-12120-2B-SX	六角法兰螺栓M12×1.25×120	Bolt, Flange M12×1.25×120	6
1100D	F04	19 50753-BEB0-0002	50753-BEB0-0002-B6	左后轮半角过渡架	Support, Rear Left Wheel Strut	1
1100D	F04	20 50754-BEB0-0002	50754-BEB0-0002-B6	右后轮半角过渡架	Support, Rear Right Wheel Strut	1
1100D	F04	22 90140-12070-2B		六角法兰螺栓M12×1.25×70	Bolt, Flange M12×1.25×70	1
1100D	F04	27 42753-BCA0-0000		气门嘴	Stem Valve	10
1100D	F04	28 42754-BCA0-0000		气门嘴帽	Cap,Valve Stem	10
1100D	F04	29 25410-BEB0-0010		左传动半轴	Half Transmission Shaft, Left	1
1100D	F04	30 25420-BEB0-0010		右传动半轴	Half Transmission Shaft, Right	1
1100D	F04	31 44901-BEB0-0001-0D		辐板轮安装螺母	Nut, Rear wheel Arm	12
1100D	F04	25410-BEB0-0010-001		传动半轴防尘盖	Dust cover, transmission shaft	4
1100D	F04	95710-12070-2B		六角法兰螺栓M12×70	Bolt, Flange M12×70	4
1100D	F05	29 94010-10B01-0B		六角螺母M10×1.25	Nut, Hex M10×1.25	2
1100D	F05	38 31310-SEC0-E000		ECU	E C U	0
1100D	F05	42 88130-BEB0-0000		内后视镜	Inner rear view mirror	1

1100D	F05	58	33122-BEB0-0000-B6	装饰灯支架	Bracket, Décor lamp	6
1100D	F05	59	95710-06020-0B	六角法兰螺栓M6×20	Bolt, Flange	6
1100D	F05	60	90210-06B01-0B	六角法兰自锁螺母M6	Lock Nut, Flange	6
1100D	F06	7	53260-BEB0-0020	转向机立柱	Knuckle Shaft, Steering	1
1100D	F06	8	53210-BEB0-0010	转向机总成	Steering Knuckle, Assy.	1
1100D	F06	13	90241-BCA0-0000-0C	圆螺母M16×1.25	Nut, Round M16×1.25	2
1100D	F06	14	53220-BCA0-0000	万向节	Ball Joint, Steering	4
1100D	F06	14	53220-BDE0-0000	万向节	Ball Joint,Steering	4
1100D	F06	16	53250-BCA0-0000	防尘罩	Dust Cover	4
1100D	F06	17.1	5324A-BEB0-0000-002	转向连接杆(连杆)	Turning Tie Rod, Right (tie rod)	2
1100D	F06	17.2	5324A-BEB0-0000-001	转向连接杆(球头)	Turning Tie Rod, Right (Ball joint)	2
1100D	F06	22	3510A-BEB0-0010	组合开关	Switch Unit	0
1100D	F06	24	53168-BEB0-0000	球头保护套	Protection cover, Ball Joint (Black)	4
1100D	F06	24	53168-BEB0-0000	球头保护套	Protection cover, Ball Joint (Black)	60
1100D	F08	8	18301-BEB0-0000	三元催化抱箍	Circlip Three-way Catalyst	1
1100D	F09	1	1720A-BEB0-0000	空滤器	Air cleaner	1
1100D	F09	5	17241-BEB0-0020	进气管	Pipe,Air-intake	1
1100D	F09	12	17116-BEB0-0000	进气管支撑弹簧	Support Spring Air-intake	1
1100D	F09		17211-BEB0-0000	空滤器滤芯	Air Filter element	4
1100D	F10	2	19100-BEB0-0001	副水箱	Water Tank,Subsidiary	1
1100D	F10	12	50329-BCA0-0000	副水箱安装带	Mounting Belt Water Tank Sub	2
1100D	F10	12	50329-BCA0-0000	副水箱安装带	Mounting Belt Water Tank Sub	4
1100D	F11	1	17620-BCC0-0002	油箱盖	Cap, Fuel Tank	1
1100D	F11	2	17513-BEB0-0000-001	加油口 I	Oil Filler I	0
1100D	F11	3	17513-BEB0-0000-002	加油口 II	Oil Filler II	0
1100D	F11	14	17530-BEB0-0000	汽油滤清器	Filter Gasoline	3
1100D	F11	14	17530-BEB0-0000	汽油滤清器	Filter Gasoline	1
1100D	F11	17	17683-BEB0-0020	出油管 II	Pipe II	3
1100D	F11	18	17540-BEB0-0000	汽油泵	Pump, Gasoline	1
1100D	F11	29	50398-BEB0-0000	汽油泵保温管	Heat preservension pipe for benzine pump	1
1100D	F13	1	87507-BEB0-E000	铭牌	Manufacturer plate	1
1100D	F13	4	89393-BEB0-0000	挡脚布套	Cover, Feet block (black)	1
1100D	F13	5	89430-BEB0-0000	储物包	Storage bag	1
1100D	F13	18	11346-SECO-0000	达众标识牌	DAZON brand	1
1100D	F13	30	87914-BEB0-0000	欧规论证标识	EEC label	1
1100D	F13	3-1	89340-BEB0-0000	保险杆帆布护套	Protective bar cover (Black)	2
1100D			89020-SECO-0000		Engine diagnostic wire and software	1
1100D			8930A-BEB0-E000		Canvas	1
1100D			38500-BEB0-0001	继电器	Relay	4
FLURO			GAXSW 18 MS			0
FLURO			RERS 18			0